



PROUD PARTNER OF

Make-A-Wish®



I wish to go to the rodeo

Daniel (DJ), 7
kidney transplant

PASSION™

Luxurious Carpet Cushion



Made of Pure
DURAPLUSH® FOAM

Comfort and Durability

- DuraPlush® foam adds luxurious comfort under carpet
- Ensures long-lasting beauty of carpet

Premium Protection

- Fresh Dimension® antimicrobial inhibits the growth of mold, mildew, and odor-causing bacteria
- Block-Out® dual moisture barriers to repel spills

Healthy Home

- Hypoallergenic
- CRI Green Label Plus-certified for indoor air quality
- 100% recyclable

Peace of Mind

- Insulates and quiets the home
- Life-of-the-Home warranty + StairGuard™ protection



Scan for more
information

Leggett & Platt will donate \$0.01 to Make-A-Wish for every square foot (\$0.09 sq. yd.) of Make-A-Wish branded carpet and cushion underlayment products now through December 31, 2025, with a minimum donation of \$100,000.

Visit LPFlooringProducts.com
for more information.



Leggett & Platt
FLOORING PRODUCTS

PASSION™

Luxurious Carpet Cushion

PROUD PARTNER OF

Make-A-Wish®

SPECIFICATIONS

Product code:	BZ0471
Thickness:	0.500"
R-value:	2.22
FHA class:	2
Roll size:	6' x 45' (30 yd ²)
Cushion color:	Blue
Triple Protection:	- Fresh Dimension® antimicrobial - Block-Out® top moisture barrier - Bottom moisture barrier
Certification:	- FHA/HUD/VA (UM72a per ASTM D3574) - CRI Green Label Plus



RECOMMENDED INSTALLATION INSTRUCTIONS

1. Always inspect the floor prior to installation to ensure it's clean and free of debris. **Inspect and test for moisture before installing any dual-moisture-barrier product.** Reference the CRI Carpet Installation Standard.
2. When laying cushion over subfloor where old glue is exposed, first sprinkle talcum, baby powder, or baking soda. This will help prevent the cushion from partially sticking to the floor, potentially causing noise.
3. If using a pad adhesive, apply a small amount in the corners of the room to help hold the cushion in place during installation. Staples may also be used around the perimeter of the room.
4. Use a flexible, moisture-resistant-type tape (no masking or other paper-based tape) at cushion seams and for covering tears, punctures, and staples.

LIFE-OF-THE-HOME LIMITED WARRANTY

Please visit LPFlooringProducts.com for detailed warranty information.



Scan for more information

Visit LPFlooringProducts.com for more information.



Leggett & Platt
FLOORING PRODUCTS